


# Vibration Severity Chart



Values shown are for filtered readings taken on machine structure or bearing

**Vibration Frequency (CPM)**